

THE PECO PERFORMANCE PRO T4900 SCHOOL SERIES THERMOSTAT

Thank you for choosing the PECO® Performance PRO™ T4900 School Series™ thermostat. The T4900 provides comfort conditioning for educational environments, reducing energy consumption and the bottom line. One-touch simplicity means users simply push the "Teacher" key to apply an energy-efficient School Schedule. The T4900 supports up to 3-HEAT/ 2-COOL configurations in conventional and heat pump applications. Users can choose between two modes in which to operate the T4900: as a standard Performance PRO or as a School Series.

The Performance PRO T4900 School Series is comprised of the T4932SCH-001 programmable and the T4932SCH-002 programmable thermostat with humidification/dehumidification control. T4900 School Series standard features include: 4 square inches of blue backlit display; Secure Digital (SD) card interface; locking cover; auto-changeover; School Schedule; inputs for occupancy/ remote sensors; three levels of keypad lockout and PIN access; furnace and UV filter reminders; Heat/Cool Demand Indicator; a 365-day calendar, 20 holidays; Power Harvesting (a.k.a. "power stealing"); and humidity control (T4932SCH-002 only).

The T4900 Series can be powered by 24 VAC or batteries or both (recommended). The T4900 Series can control up to 7 outputs and monitor three external sensors (including a CO₂ sensor). The T4900 Series mounts on any PECO Performance PRO Series common wallplate.

APPLICATIONS AND FEATURES

The PECO Performance PRO thermostat is intended for use in conventional and heat pump applications.

- System mode selections: Off-Heat-Cool-Auto-Emergency
- Stages: 1 Heat/1 Cool, 2 Heat/1 Cool, 1 Heat/2 Cool; 2 Heat/ 2 Cool; 3 Heat/ /2 Cool
- Fan control: Cycling (Auto) or Continuous (On); 1 Speed
- Permanent memory: All device settings are stored in permanent memory.
- Connections for Remote Sensors (indoor/ outdoor/ occupancy/ CO₂)
- SD card interface (card not included)

! CAUTION!

- 24 VAC low-voltage thermostat. Do **not** install on voltages higher than 30 VAC.
- Use copper wire only; insulate or cap off (with wire nuts) all unused leads.
- Use care to avoid electrostatic discharge to the thermostat.

FRONT PANEL REFERENCE: T4900 CONTROLS & DISPLAY




Figure 1. T4900 Thermostat (Home Display).




Figure 2. T4900 Thermostat back view (with wallplate attached).

! WARNING

- READ THESE INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO INSTALL, OPERATE, OR SERVICE THIS THERMOSTAT.
- Failure to observe safety information and comply with instructions could result in PERSONAL INJURY, DEATH AND/OR PROPERTY DAMAGE.
- To avoid electrical shock or damage to equipment, disconnect power before installing or servicing and use only wiring with insulation rated for full thermostat operating voltage.
- To avoid potential fire and/or explosion do not use in potentially flammable or explosive atmospheres.
- Retain these instructions for future reference.
- This product, when installed, will be part of an engineered system whose specifications and performance characteristics are not designed or controlled by PECO. Review applications and national and local codes to assure that the installation will be functional and safe.

PRODUCT SPECIFICATIONS

Temperature Control

Range: 50° to 90° F (10° to 32° C)

Differential: 1° F (0.5° C)

Input Power: 24 VAC (20-30 VAC) 50/60 Hz (+/- 10%) or AA alkaline batteries (both recommended); 5mm terminals accept 14-24 AWG stranded or solid wire.

Operating Temperature: 0° to 120°F (-17° to 48°C)

Shipping Temperature: -20° to 130°F (-28° to 54°C)

Operating Humidity: 5% to 95% RH, non-condensing

Physical Dimensions: T4900 Thermostat: 4.3" H x 5.7" W x 1.3"D

with 2.7" x 1.5" / 4.05 square inch liquid crystal display (LCD)

Output Ratings

Voltage (50/60 Hz): 20-30 VAC

Current: 0.02-1.0 A per terminal; W1 (B/O), W2 (AUX), G, A, E, Y1, Y2.

Note: Collectively, total current draw must not exceed 2.5 A.

INSTALLATION INSTRUCTIONS

Select an appropriate thermostat location

Locate the thermostat about five feet (1.5 m) above the floor on a wall in an area with good ventilation and an average temperature, where it will be responsive to changes in room temperature.

The Performance PRO T4900 School Series may be mounted on a:

- Horizontal or vertical 2" X 4" device box
- Horizontal 4" X 4" device box
- Flat surface

Do **not** locate the thermostat where it can be affected by:

- Direct sunlight
- Drafts or dead areas behind doors
- Radiant heat from appliances
- Concealed pipes or chimneys
- Outside walls or unheated/uncooled areas

Required components (not included, unless otherwise specified):

- Two new AA batteries (included)
- Screws and wall anchors (included)
- Screwdrivers: Phillips (for wallplate); small flathead (for terminal blocks)
- Drill with 3/16" drill bit (or 7/32" for plaster)
- Wirecutter and stripper
- Level
- Performance PRO School Series T4900 Thermostat (included)
- Performance PRO School Series T4900 Thermostat Operating Manual (included)




Note: Secure Digital (SD) card interface (card not included) provides for quick transfer of customized settings to or from the thermostat. For instructions, see "Load SD Card Settings" in the Operating Manual. For more information on PECO's configurator, visit: www.pecomanufacturing.com/controls/

PART I: INSTALL THE WALLPLATE

1. Position the wallplate on the wall with the directional arrow pointing up (see Fig. 3) and terminal blocks facing outward.

Figure 3:
Position the wallplate on the wall. Pull wires through wiring passage.



2. Pull equipment wires through the wallplate wiring passage (see Fig. 3).
3. Use a level to determine the best horizontal wallplate mounting position.
4. Mark positions of screw holes (two at minimum) with a pencil and remove wallplate.
5. Drill holes at pencil-marked locations (3/16" for drywall, 7/32" for plaster).
6. Insert the wall anchors in the holes, tapping them into place.
7. Mount the wallplate onto the wall and insert screws through mounting holes. Assume that all loose wires come through the center opening of the wallplate (see Fig. 3).
8. Cap off any unused wires and terminate properly according to local building codes.

PART II: ATTACH WIRES TO THERMOSTAT WALLPLATE

1. Select the terminal designations that correspond to the system type (see Table 1).



- **WARNING:** Disconnect power **before** beginning installation.
- **CAUTION:** Use copper wire only. Insulate or wire-nut all unused leads.
- Use care to **avoid** electrostatic discharge to thermostat

TABLE 1. TERMINAL DESIGNATIONS & SYSTEM TYPES

Conventional Terminal Letters		Heat Pump Terminal Letters	
C	Unswitched side, 24 VAC	C	Unswitched side, 24 VAC
W1	Stage 1 Heat	B/O	Reversing Valve
W2	Stage 2 Heat	AUX	Auxiliary (Stage 3 Heat)
G	Fan	G	Fan
A	Economizer/Damper/ Humidity	A	Economizer/Damper/ Humidity
E	Stage 3 Heat	E	Emergency Heat
Y1	Stage 1 Cool	Y1	Compressor Stage 1, Heat /Cool 1
Y2	Stage 2 Cool (or Dehumidify)	Y2	Compressor Stage 2, Heat /Cool 2 (or Dehumidify)
RH	Power for heating, switched side, 24 VAC	RH	Power for heating, switched side, 24 VAC
RC	Power for cooling, switched side, 24 VAC	RC	Power for cooling, switched side, 24 VAC
SC	Sensor Common	SC	Sensor Common
S1	Indoor/ Outdoor Remote Sensor	S1	Indoor/ Outdoor Remote Sensor
S2	Occupancy Sensor/ Setback Input	S2	Occupancy Sensor/ Setback Input
S3	CO ₂ Sensor/ Outdoor Remote Sensor	S3	CO ₂ Sensor /Outdoor Remote Sensor with Heat Pump Compressor Lockout*

System Type 1: 1H/1C Conventional	
TERM	Function
C	Common
W1	Heat
W2	
G	Fan
A	Economizer/Damper
E	
Y1	Cool
Y2	
RH	Power for Heating
RC	Power for Cooling

System Type 2: 1H/1C Heat Pump	
TERM	Function
C	Common
B/O	Reversing Valve
AUX	
G	Fan
A	Economizer/Damper
E	
Y1	Compressor
Y2	
RH	Power for Heating
RC	Power for Cooling

System Type 3: Heat only (without fan)	
TERM	Function
C	Common
W1	Heat
W2	
G	
A	Economizer/Damper
E	
Y1	
Y2	
RH	Power for Heating
RC	

System Type 4: Heat only with fan	
TERM	Function
C	Common
W1	Heat
W2	
G	Fan
A	Economizer/Damper
E	
Y1	
Y2	
RH	Power for Heating
RC	

System Type 5: Cool only	
TERM	Function
C	Common
W1	
W2	
G	Fan
A	Economizer/Damper
E	
Y1	Cool
Y2	
RH	Power for Heating
RC	Power for Cooling

System Type 6: 2H/1C Heat Pump (Aux.)	
TERM	Function
C	Common
B/O	Reversing Valve
AUX	Auxiliary Heat
G	Fan
A	Economizer/Damper
E	Emergency Heat
Y1	Compressor
Y2	
RH	Power for Heating
RC	Power for Cooling

System Type 7: 2H/2C Conventional	
TERM	Function
C	Common
W1	Heat 1
W2	Heat 2
G	Fan
A	Economizer/Damper
E	
Y1	Cool 1
Y2	Cool 2
RH	Power for Heating
RC	Power for Cooling

System Type 8: 2H/1C Conventional	
TERM	Function
C	Common
W1	Heat 1
W2	Heat 2
G	Fan
A	Economizer/Damper
E	
Y1	Cool
Y2	
RH	Power for Heating
RC	Power for Cooling

System Type 9: 1H/2C Conventional	
TERM	Function
C	Common
W1	Heat
W2	
G	Fan
A	Economizer/Damper
E	
Y1	Cool 1
Y2	Cool 2
RH	Power for Heating
RC	Power for Cooling

System Type 10: 2H/2C Heat Pump	
TERM	Function
C	Common
B/O	Reversing Valve
AUX	
G	Fan
A	Economizer/Damper
E	
Y1	Compressor 1
Y2	Compressor 2
RH	Power for Heating
RC	Power for Cooling

ⓘ ALL ELECTRICAL LOADS MUST BE CONNECTED TO TERMINAL C (24 VAC).

*Note: Heat Pump Compressor Lockout requires connection of Outdoor Remote Sensor to S1 or S3.

System Type 11: 3H/2C Heat Pump	
TERM	Function
C	Common
B/O	Reversing Valve
AUX	Auxiliary Heat
G	Fan
A	Economizer/Damper
E	Emergency Heat
Y1	Compressor 1
Y2	Compressor 2
RH	Power for Heating
RC	Power for Cooling

System Type 12: 3H/1C Conventional	
TERM	Function
C	Common
W1	Heat 1
W2	Heat 2
G	Fan
A	Economizer/Damper
E	Heat 3
Y1	Cool 1
Y2	
RH	Power for Heating
RC	Power for Cooling

System Type 13: 3H/2C Conventional	
TERM	Function
C	Common
W1	Heat 1
W2	Heat 2
G	Fan
A	Economizer/Damper
E	Heat 3
Y1	Cool 1
Y2	Cool 2
RH	Power for Heating
RC	Power for Cooling

CAUTION: Do not connect unused wires together

PART II: ATTACH WIRES TO THERMOSTAT WALLPLATE (CONT.)

- Using a small flathead screwdriver, loosen the screws on the terminal blocks that correspond to the system type (see Table 1).
- Strip the insulation of each wire at a proper length (about 1/4" or 64 cm).
- On the wallplate, insert wires into the terminal blocks that correspond to the system type, then re-tighten each screw for each terminal (see Fig. 4, enlarged area).
- Note: Do not over-tighten screws or use excessive force.**
- Assure that no uninsulated wires are exposed: Cap off and place a wire-nut on any unused wires. Assure that the attached wires fit into the cavity on the back side of the thermostat.




Figure 4. Insert wires into appropriate terminal blocks.

PART III: CONNECT POWER TO THE THERMOSTAT WALLPLATE

- Choose from the following options to power the thermostat.

Power Options

The T4900 School Series will operate on 24VAC power and/or two AA batteries (both are recommended). Choose from three methods to connect power to the thermostat.

- Batteries only (AA alkaline)
- 24 VAC direct connection only
- 24 VAC with AA battery backup (highly recommended)

Wiring 24 VAC Common

- Single-Transformer System:** Connect the common side of the transformer to the "C" screw terminal of the thermostat wallplate. Assure that the metal jumper connects "RC" and "RH." Connect power side to the RC/RH and assure that the jumper remains in place.
- Two-Transformer System:** The T4900 School Series is shipped with a jumper connecting terminals RH and RC. If the heating and cooling equipment do not use separate transformers, leave this jumper in place. If separate transformers are required, remove this jumper. With the jumper removed, connect RC to the power side of the cooling transformer. Connect RH to the power side of the heating transformer; then connect both the heating and cooling commons together to terminal C (Common).

PART IV: INSTALL BATTERIES & REMOVE TAB

- Insert two AA batteries (included) into the back compartment of the thermostat, where indicated (see Fig. 5).




Figure 5. Insert two AA batteries in back of thermostat.

- Remove the plastic insulator tab from the back side of the thermostat (see Fig. 6). **IMPORTANT:** The insulator tab must be removed before setting the real-time clock.




Figure 6. Remove the insulator tab from thermostat before operation.

PART V: SET THE CLOCK, MONTH, AND DAY

When power is first applied to the thermostat, it will activate the clock display (see Fig. 7). It is recommended that time and day are entered before performing advanced configuration. Follow the procedure below to set the clock, month, and day.

- Press ▲ / ▼ to select 12 or 24 HR mode, then press **Next**.
- Press ▲ / ▼ to select clock hour, then press **Next**.
- Press ▲ / ▼ to select clock minutes, then press **Next**.
- Press ▲ / ▼ to select clock year, then press **Next**.
- Press ▲ / ▼ to select current month, then press **Next**. **Note: Mo** (month) appears.
- Press ▲ / ▼ to select current date. **Note: Days** appears.
- Press **Done** to finish clock mode.




Figure 7. Clock must be set before performing advanced configuration.

PART VI: VERIFY SYSTEM SETTING IS TURNED OFF

Note: The flashing option is the default selection.

- Press any key to enter the Home Display.
- Press **System** to enter system settings.
- Press ▲ / ▼ to select "Off," then press **Done**.
- Press **Fan** key to enter fan mode.
- Press ▲ / ▼ to select "Auto," then press **Done**.

PART VII: PERFORM ADVANCED CONFIGURATION

Perform advanced configuration and program the desired schedule before attaching the thermostat to the wallplate. Advanced configuration is done by simultaneously pressing the lower left and lower right keys for about five seconds (see Fig. 8), which gives user access to Service Menus. Use Table 2 of this Installation Guide to set each desired Service Menu item. Advanced configuration allows the user to configure the thermostat to match the system type and to customize several thermostat settings.





Figure 8. Access Service Menus by pressing the lower left and lower right keys simultaneously.

PART VIII: MOUNT THE T4900 ONTO THE WALLPLATE

1. Position the thermostat slightly above the mounted wallplate (see Fig. 9), then secure the hooks on the back side of the thermostat to the hinge pockets on the wallplate.


Note: The top back side of the thermostat should slip into the hinge pockets easily. Do not use excessive force.

Figure 9.
Secure the hooks on the back side of the thermostat to the wallplate.



2. Align the pins on the back side of the thermostat with the terminal blocks on the wallplate.
3. Gently bring down the thermostat onto the wallplate so the pins on the back of the thermostat fit into the terminal blocks on the wallplate (see Fig. 10).
4. Attach the retaining screw to the underside of the thermostat as shown (see Fig. 10).

Figure 10.
Mount the thermostat so pins on back fit into the terminal blocks on the wallplate.



Retaining screw

PART IX: VERIFY THERMOSTAT OPERATION WITH SYSTEM TESTS

System test verification is highly recommended to verify thermostat operation. Follow at least one procedure in the system tests below. Refer to the Service Menus (see Table 2) for more system tests. For all system tests, press **Next** to continue to the following system test, which is the next available Service Menu. Press **Done** only if finished performing all system tests. Pressing **Done** exits the Service Menus and turns off all active outputs.

SYSTEM TEST MAIN OUTPUT (HEAT)

1. On the thermostat, press the lower left and lower right keys simultaneously for about five seconds. **Next**, **Go Back**, and **Done** appear (see Fig. 11).
2. Press **Next** until Service Menu 610 appears in the display. (Default value "00" appears below Service Menu.)

Figure 11.
Service Menu 610 allows user to perform System Test (Heat).



3. In Service Menu 610, press **▲** / **▼** to select option "01," Heat Stage 1 (see Fig. 12). **Note:** If 01 is selected, the thermostat will activate the associated output for up to 10 minutes. The user should observe that the fan output (with heat) turns on. The user may also test more stages of heat according to what is available for the system type.




Figure 12.
Press **Done** to complete test and exit Service Menus or **Next** to continue to the next test.

4. Press **Done** to complete the system test and exit the Service Menus. After verifying the system test, the outputs are disabled and the fan will stop.

Optional: The user may perform additional system tests by pressing **Next** to access more Service Menus (see note below).

SYSTEM TEST FAN (OPTIONAL)

The following instructions assume that the user enters the Service Menus from the Home Display; it does not assume that the user has followed in sequence from the previous section. If continuing from the previous section on this page, skip to Step 2 below.

1. On the thermostat, press the lower left and lower right keys simultaneously for about five seconds. **Note:** **Next**, **Go Back**, and **Done** appear (see Fig. 13).
2. Press **Next** until Service Menu 620 appears in the display. (The default value "00" for appears below Service Menu.)




Figure 13.
Service Menu 620 allows user to perform a System Test Fan.

3. In Service Menu 620, press **▲** / **▼** to select option "01" (to enable fan output). **Note:** If 01 is selected, the thermostat will activate the associated output for up to 10 minutes. The user should observe that the fan output will turn on.




Figure 14.
Press **Done** to complete testing and exit Service Menus, or **Next** to continue tests.

4. Press **Done** to complete the system test. After verifying the system tests, the outputs are disabled.

Optional: The user may perform additional system tests by pressing **Next**. Additional system tests include (See Table 2): 600, System Test Main Output (Cool); 630, System Test Emergency Output; 640, System Test Economizer.

TABLE 2. ADVANCED CONFIGURATION: SERVICE MENUS

To access Service Menus, simultaneously press lower left and lower right keys. Service Menu availability is dependent upon system type and upon system configuration. For abbreviation in text, SM=Service Menu.

MENU	FEATURE	OPTIONS	STD. MODEL DEFAULT	DESCRIPTION / COMMENTS
100*	Schedule Format	0-4	1	Select the desired schedule format. Select 0-3: Performance PRO, standard format; or select 4: School Schedule format. 0 = nonprogrammable 1 = programmable 2 = 5-1-1 schedule 3 = 5-2 schedule 4 = School Schedule
101	Daylight-Saving Time	0,1	0	Select daylight-saving time as it follows standard format in U.S.: It begins second Sunday of March at 2:00 AM and ends on the first Sunday of November at 2:00 AM. 0 = Disabled 1 = Enabled (2007 U.S. Format)
110	System Type	1-13	1	Select the appropriate system configuration (determines available Service Menus). 1 = 1 Heat/1 Cool conventional 2 = 1 Heat/1 Cool heat pump 3 = Heat only without fan (2-wire systems) 4 = Heat only with fan 5 = Cool only 6 = 2 Heat/1 Cool heat pump (with auxiliary heat) and Emergency (Em) heat 7 = 2 Heat/2 Cool multistage conventional 8 = 2 Heat/ 1 Cool multistage conventional 9 = 1 Heat/ 2 Cool multistage conventional 10 = 2 Heat/ 2 Cool heat pump (no auxiliary heat) 11= 3 Heat/ 2 Cool heat pump (with auxiliary heat) and Emergency (Em) heat 12 = 3 Heat/ 1 Cool conventional 13= 3 Heat/ 2 Cool conventional
120	Fan Control (heating)	0,1	0	0 = Fossil Fuel: Gas/Oil/Propane heat (equipment controls heating fan) 1 = Electric Furnace (thermostat controls heating fan)
130	Changeover valve (B/O terminal)	0,1	0	0 = B/O terminal controls valve in cooling 1 = B/O terminal controls valve in heating
140	Auxiliary Heat	0,1	0	0 = Electric backup heat 1 = Fossil fuel backup heat
150	Backlight	0,1	0	0 = Backlight temporarily on 1 = Backlight always on (low intensity, 24V only)
170	Remote Sensors/ CO ₂ Sensor	0-8	0	Select sensor if used. Contact PECO for information on the T4900 School Series Indoor Remote Zone Sensor. 0 = No Sensor 1 = Indoor Sensor 2 = Outdoor Sensor display only 3 = Outdoor Sensor display and lockout control 4 = Indoor, Outdoor Sensor display only 5 = Indoor, Outdoor Sensor display and lockout control 6 = S3 input configured for CO ₂ sensor, no indoor sensor. 7 = S3 input configured for CO ₂ and S1 for indoor sensor. 8 = S3 input configured for CO ₂ and S1 for outdoor sensor.
172	System Shutdown (for S1 Terminal)	0-4	0	A dry contact switch can be connected to S1 input on the T4900 terminal block. When detected in an active state, all HVAC outputs are turned OFF (same as system off), and Service Indicator (wrench) is displayed on LCD. 0 = Probe, no switch (default) 1 = Shutdown on open 2 = Shutdown on closed 3 = Shutdown on open with remote temperature probe 4 = Shutdown on closed with remote temperature probe
180	Heat Pump Compressor Lockout	0-45°F (-18°C - 7°C)	0	If an outside sensor is used, the compressor will be locked out when the outside air temp is below the value selected. 0 = None 15°F (-9°C); 20°F (-7°C); 25°F (-4°C); 30°F (-1°C); 35°F (2°C); 40°F (4°C); 45°F (7°C)
190	Heat Pump Auxiliary Lockout	0- 60°F (-18°C - 15°C)	0	If an outside sensor is used, the auxiliary heat will be locked out when the outside air temperature is above the value selected. 0 = None 40°F (4°C); 45°F (7°C); 50°F (10°C); 55°F (13°C); 60°F (16°C)
230	Furnace Filter Timer	0; 10; 30; 60; 90; 120; 365	0	Sets a Furnace Filter Timer reminder; appears on digital display when timer expires (if programmed). 0 = Off 10 days; 30 days; 60 days; 90 days; 120 days; 365 days

TABLE 2. ADVANCED CONFIGURATION SERVICE MENUS (CONT.)

MENU	FEATURE	OPTIONS	STD.MODEL DEFAULT	DESCRIPTION / COMMENTS
232	Enable UV Filter Timer	0-1	0	Activates the UV Filter Timer. UV Filter timer measures the on-time for Fan output in service of heat, cool, humidify, or dehumidify (Note: UV lamp life varies by manufacturer. PECO is not responsible for lamp life nor for UV filter.) 0 = UV timer disabled 1 = UV timer enabled
233	UV Filter Timer Hours	0-250	120 (hundreds of hours)	Reports UV Filter Timer in hundreds of hours. (Default: Number of hours remaining 120 = 12,000 hours). Service Indicator (wrench) is shown in Default Display when timer expires. When the UV Filter Timer expires, in Home Display the clock area alternates between the time display and "F 01."
240	Number of Program Periods	2; 4 events	4	2 = 2 events per day 4 = 4 events per day
250	Clock format	12 or 24 Hours	12	12 = 12-hour clock mode 24 = 24-hour clock mode
260	Temperature Format (°F or °C)	0,1	1	0 = Celsius 1 = Fahrenheit
270	Fan Off Delay Heat	0-99 Seconds	0	Select the amount of time (in seconds) that the fan will run after the thermostat heat outputs are turned off.
280	Fan Off Delay Cool	0-99 Seconds	0	Select the amount of time (in seconds) that the fan will run after the thermostat cool outputs are turned off.
290	Range Low	50-90 °F or 10-32°C	50°F (10°C)	Choose the <u>lowest</u> selectable temperature setpoint value. Only available with Performance PRO settings (see SM 100).
300	Range High	50-90 °F or 10-32°C	90°F (32°C)	Choose the <u>highest</u> selectable temperature setpoint value. Only available with Performance PRO settings (see SM 100).
302	Teacher Key Heat Setpoint Increase	0-10 °F	3 °F	Sets number of degrees that teacher can increase the temperature <u>above</u> the Occupied Heat Setpoint.
303	Teacher Key Heat Setpoint Decrease	0-10 °F	3 °F	Sets number of degrees that teacher can decrease the temperature <u>below</u> the Occupied Heat Setpoint.
304	Teacher Key Cool Setpoint Increase	0-10 °F	3 °F	Sets number of degrees that teacher can increase the temperature <u>above</u> the Occupied Cool Setpoint.
305	Teacher Key Cool Setpoint Decrease	0-10 °F	3 °F	Sets number of degrees that teacher can decrease the temperature <u>below</u> the Occupied Cool Setpoint.
310	Setback Low	Off; 50-82°F or 11-27°C	55°F (13°C)	Select the heat setpoint for setback mode. Only available with Performance PRO settings (see SM 100). 0 = Off 50-82°F (11-27°C)
320	Setback High	Off; 58-90°F or 11-32°C	90°F (32°C)	Select the cool setpoint for setback mode. Only available with Performance PRO standard settings (see SM 100). 0 = Off 58-90°F (11-32°C)
330	Zone Temp Offset	+/-9°F or +/- 4.5°C	0°F (18 °C)	Adjusts the displayed value; may differ from actual zone temperature.
340	Keypad Lockout	0-3	0	Restricts access to certain features of device; Service Menu still available if enabled. 0 = No keypad lockout (Default) 1 = Disables Schedule and System keys 2 = Disables Schedule, System, and Fan keys 3 = Disables all keys
341	Enable Pin Access	0,1	0	Applies a 3 digit access code to enter Service Menu 342 0 = Disable 1 = Enable
342	Set PIN Access Code	000-999	000	Choose a 3-digit code.
350	Fan Mode Enable	1-3	3	1 = ON: Fan is turned on regardless of demand. 2 = Auto: Fan is turned on according to heating or cooling demand. 3 = ON or Auto: Allows occupant to select either 1 or 2 above.

TABLE 2. ADVANCED CONFIGURATION SERVICE MENUS (CONT.)

MENU	FEATURE	OPTIONS	STD.MODEL DEFAULT	DESCRIPTION / COMMENTS
360	System Mode Enable	0-3	1	Allows ability to determine which system modes the occupant can select. 0 = OFF, Auto 1 = OFF, Heat, Cool, Auto 2 = OFF, Heat, Cool 3 = Heat, Cool, Auto
370	Economizer/Outside Air Damper Control	0-4	0	0 = Off 1 = Time Based Output 2 = Economizer 3 = Continuous Outside Air Damper 4 = Cycled Outside Air Damper (Note: Cycles on demand if CO ₂ Sensor is applied and configured.)
380	Minimum Deadband Adjustment	3-10°F, 1.5-5°C	3°F	Select a changeover deadband value to prevent short cycling between heating and cooling modes. The value is adjustable to meet various HVAC system requirements.
388	Restart Occupancy Sensor Count when not-enabled.	0-2	0	Providing an "occupied" input signal behaves the same as pressing the Teacher key. Note: In the event that the teacher button and the occupancy sensor are not in the same state, the Teacher key takes precedence. 0 = No occupancy sensor installed in system. 1 = Status changes to unoccupied after time set in occupied time setting runs out, regardless of occupancy sensor input. 2 = Status remains as occupied as long as occupancy sensor indicates room is occupied.
390	Pre-Occupancy Purge	0-3 hours	0 hours	Select to energize fan for selected number of hours (0-3) prior to all occupied events.
391	Adaptive Pre-Conditioning Schedule (APCS)	0-1	0	Enables adaptive pre-conditioning schedule (and requires input by user or occupancy sensor after enabled). 0 = Disabled 1 = Enabled; state learns pre-purge and recovery schedule.
392	Persistence (for APCS)	1-4	2	Selects the number of weeks that an APCS event shall remain in the schedule. 1 = Event will be removed from the schedule the first time that it does not recur.
395	Maximum Override Time Limit	0=Time until next event; or 1-4 hours	3	Restricts the duration that a temporary hold can be set. The temporary hold is limited by the maximum amount of time as defined in this Service Menu. 0 = Remainder of time until the next scheduled event. 1 = 1 Hour 2 = 2 Hours 3 = 3 Hours 4 = 4 Hours
396	School Schedule Default Occupied Duration When Enabled	0; 0:15; 0:30; 1; 2; 3; 4; 6; 8; 99	99 (max.)	Sets the <u>default occupied duration</u> , when Teacher key is pressed, during School Schedule "Enabled" period. 0 = Occupied duration not available to teacher. Occupied duration set to "Max occupied time when enabled" setting. 99 = Occupied duration is available to teacher; defaults to "Max occupied duration when enabled" setting.
397	School Schedule Default Occupied Duration When Disabled	0:15; 0:30; 1; 2; 3; 4; 6; 8	0:15	Sets the default occupied duration, when Teacher key is pressed, in School Schedule "Disabled" period.
398	School Schedule Max. Occupied Duration When Enabled	0:15; 0:30; 1; 2; 3; 4; 6; 8; 99	1	Sets the maximum <u>occupied duration</u> that the user can enter during the "Enabled" schedule period. 99 = Thermostat can be set to remain occupied until the end of the Enabled period.
399	School Schedule Max. Occupied Duration When Disabled	0; 0:15; 0:30; 1; 2; 3; 4; 6; 8	0:15	Sets the maximum <u>occupied duration</u> that the user can enter during the "Disabled" schedule period 0 = Thermostat will not become occupied in Disabled schedule period.
400	Cycles Per Hour (CPH) Cooling Stage 1	0-6 CPH	3 CPH	Defines the number of cycles per hour for cooling (Stage 1). Select 0 to enable ON-OFF control for Stage 1 cooling.
410	Cycles Per Hour (CPH) Cooling Stage 2	0-6 CPH	3 CPH	Defines the number of cycles per hour for cooling (Stage 2). Select 0 to enable ON-OFF control for Stage 2 cooling.
420	Cycles Per Hour (CPH) Heating Stage 1	0-12 CPH	5 CPH	Defines the number of cycles per hour for heating (Stage 1). Select 0 to enable ON-OFF control for Stage 1 heating.
430	Cycles Per Hour (CPH) Heating Stage 2	0-12 CPH	5 CPH	Defines the number of cycles per hour for heating (Stage 2). Select 0 to enable ON-OFF control for Stage 2 heating.

TABLE 2. ADVANCED CONFIGURATION SERVICE MENUS (CONT.)

MENU	FEATURE	OPTIONS	STD.MODEL DEFAULT	DESCRIPTION / COMMENTS
450	Cycles Per Hour (CPH) Emergency Heating & Stage 3 Heat	0-12 CPH	5 CPH	Defines the number of cycles per hour for heating. Select 0 to enable ON-OFF control for Emergency Heating & Stage 3 Heat.
460	Heat Recovery Rate	0-18°F/Hr 0-10°C/Hr	5°F/Hr	Defines the rate at which the device achieves the heat comfort setpoint. Select 0 to disable ramp recovery.
470	Cool Recovery Rate	0-18°F/Hr 0-10°C/Hr	5°F/Hr	Defines the rate at which the device achieves the cool comfort setpoint. Select 0 to disable ramp recovery.
480	Minimum Off Time	1-10 minutes	4 minutes	Sets the minimum off time for both the heat and cool output.
482	Random Start	0-2	0	0 = Random start disabled. 1 = Random start enabled, stat powered by batteries only. 2 = Random start enabled, stat powered by AC power, or AC power AND batteries. Note: To use random start on AC power up, SM 482 must be set to 2 so that thermostat will detect AC power. When SM 482 is set to 2, loss of AC power will cause thermostat to turn all equipment OFF until power is restored and random start time has expired.
483	Maximum Start Time Offset	3,5,10,15,30	5	Maximum start time offset. Start time offset will be randomized between 0 and this number of minutes.
484	Current Start Time Offset	---	---	Displays the randomized start time offset value in minutes.
486	Evaporator Drain Cycle	0-1	0	Disables the ventilation output until the drain cycle is complete. Note: Drain cycle lasts about 4 minutes. 0 = Evaporator drain cycle disabled. 1 = Evaporator drain cycle enabled.
490	Humidity Control Enable (Select models only)	0-3	0	Selects how humidity will be controlled. When dehumidify control is enabled, the Y2 terminal becomes dehumidify. Note: If option 3 is selected, Service Menu 491 becomes available. 0 = Disabled 1 = Dehumidify Control 2 = Humidify Control 3 = Dehumidify and Humidify Control
491	Humidity Deadband	10-50	30% relative humidity (RH)	Selects the deadband in %RH between the humidify and dehumidify setpoints. Note: If option 3 is selected in Service Menu 490, Service Menu 491 becomes available. 10; 20; 30; 40; 50
500	Programmable/Intermittent Fan	0-2	0	0 = Disable 1 = Programmable Fan: Fan operates continuously in occupied periods or with demand in unoccupied periods. 2 = Intermittent Fan: Fan operates based on the on and off times set in menus 501 and 502.
501	Intermittent Fan On Time	1-60 minutes	5 minutes	Defines the on time for the Intermittent Fan.
502	Intermittent Fan Off Time	0-60 minutes	25 minutes	Defines the off time for the Intermittent Fan. Select 0 for continuous fan.
510	Power Harvesting Enable (For use on systems in which a Common "C" power wire is unavailable)	0-3	0	Options 1-3 draw a small amount of current from load wire indicated to supplement battery supply. 0 = No power harvesting is available. 1 = Use Y1 as the battery supplement. 2 = Use W1 as the battery supplement. 3 = Use both Y1 and W1 as the battery supplement Warning: Power Harvesting is intended to be used only as a battery supplement. If enabled, the feature preserves battery life. If Power Harvesting is not compatible with your system, select "0" (default) to disable. If thermostat is powered from AC, select only "0" or off. Consult a technician if you have questions.
520	Default Display Icons	0-4	0	Select icons that will be displayed in the Default Display screen. 0 = Time, Temp, SP 1 = Time, Temp 2 = Time 3 = Temp 4 = None
530	Revision	—	—	Displays firmware revision information (for technician); not adjustable.
540	Factory Default Reset	0,1	0	Select 1 (enable) to restore factory default settings for thermostat. Select 0 to disable. 0 = Disable 1 = Enable Note: Press "Done" key to complete process.
541	Clear APCS Schedule	0-1	0	0 = No effect 1 = Clears APCS schedule. Menu resets to 0 after Done key is pressed.

TABLE 2. ADVANCED CONFIGURATION SERVICE MENUS (CONT.)


MENU	FEATURE	OPTIONS	STD.MODEL DEFAULT	DESCRIPTION / COMMENTS
600	System Test Main Output (Cool)	0-2	0	Select an option to activate the fan output for 10 minutes; select 0, Done or a different Service Menu to disable. 0 = Disable 1 = Cool Stage 1 2 = Cool Stage 2
610	System Test Main Output (Heat)	0-3	0	Select an option to activate the fan output for 10 minutes; select 0, Done or a different Service Menu to disable. Note: Outputs will be activated based upon the system configuration. 0 = Disable (Default) 1 = Heat Stage 1 2 = Heat Stage 2 3 = Heat Stage 3
620	System Test Fan Output	0,1	0	Select 0 or 1 to activate the fan output for 10 minutes; select 0, Done or a different Service Menu to disable. 0 = Disable Fan Output 1 = Enable Fan Output Note: Outputs will be activated based upon the system configuration.
630	System Test Emergency Output	0,1	0	Select 0 or 1 to activate the Emergency output for 10 minutes; select 0, Done or a different Service Menu to disable. 0 = Disable Emergency Output 1 = Enable Emergency Output
640	System Test Economizer	0,1	0	Select 1 to activate the Economizer output for 10 minutes; select 0, Done or a different Service Menu to disable. 0 = Disable Economizer Output 1 = Enable Economizer Output

PART X: SET PIN ACCESS FOR SERVICE MENUS (OPTIONAL)

Creating a PIN access code allows the installer to restrict access to Service Menu. First, PIN access must be enabled in Service Menu 341; second, a three-digit code must be created in Service Menu 342. After these two Service Menus are properly configured, the thermostat requires the user to enter a PIN access code to enter the Service Menus.

1. On the thermostat, press the lower left and lower right keys simultaneously for about five seconds. **Next**, **Go Back**, and **Done** appear (see Fig. 15).
2. Press **Next** until Service Menu 341 (Enable/Disable PIN Access) appears in the display. (Default value "00" appears below Service Menu.)
3. In Service Menu 341, press **▲ / ▼** to change digit (flashing) value to "01" (see Fig. 16).
Note: Selecting 01 enables PIN access for the thermostat Service Menus, and selecting it is necessary to show Service Menu 342.

Figure 15. Service Menu 341 allows user to restrict access to Service Menus.



VERIFY PIN ACCESS CODE

Enter the PIN access code upon entering the Service Menus. **Note:** Flashing digit is active. Change digit using the **▲ / ▼** keys. The active (editable) digit moves from right to left.

1. On the thermostat, press the lower left and lower right keys simultaneously for about five seconds. **Note:** Flashing three-digit code, **Next**, and **Done** appear (see Fig. 17).
2. Press **▲ / ▼** to change value of digit furthest to the right, then press **Next**.
3. Press **▲ / ▼** to change value of digit in middle, then press **Next**.
4. Press **▲ / ▼** to change value of digit furthest to left, then press **Done**.
Note: After step 4 is complete, user is allowed access to Service Menus. **Next**, **Go Back**, **Done**, and Service Menu 100 appear.

4. Press **Next**.
5. In Service Menu 342, press **▲ / ▼** adjust values and create a three-digit PIN access code. The flashing three-digit code appears in the clock area (see Fig. 16).
Note: Write down the PIN access code, and keep it in a safe place.
6. Press **Done** when finished.

Figure 16. Service Menu 342 allows user to create a PIN access code.





Figure 17. PIN access code flashes when user enters Service Menus (after enabling PIN access).

PART XII: T4900 SERIES PERFORMANCE PRO SENSORS

The T4900 School Series is also compatible with PECO sensors, which provides optimal control of the environment and low maintenance. Following are sensor wiring diagrams for temperature averaging and installation instructions for the Indoor Remote Zone Sensor and Outdoor Remote Sensor. (Note: Terminal designations for sensors shown in Table 4.)

TABLE 4. TERMINAL DESIGNATIONS FOR SENSORS

PECO SENSORS	Model Number	Terminal	T4900 Compatible
Indoor Remote Sensor	SP155	S1	■
Outdoor Remote Sensor	P/N 70327	S1/ S3	■
Occupancy Sensor	SB200	S2	■
CO ₂ Sensor	SC500	S3	■

To learn more about the benefits of PECO sensors visit www.pecomanufacturing.com. Or call 1-800-874-8547 to speak with a service representative.

TABLE 5. ZONE SENSOR MAXIMUM LENGTH AND WIRE SIZE

Distance from Unit to Control	Recommended Wire Size
000 - 150 feet (0-46 m)	22 gauge
151 - 240 feet (46-73 m)	20 gauge
241 - 385 feet (73-117 m)	18 gauge
386 - 610 feet (118-186 m)	16 gauge
611 - 970 feet (186-296 m)	14 gauge

NOTE: Use appropriate wire for outdoor use.

LOCATE & MOUNT PECO OCCUPANCY SENSOR (SB200-001)

Please use the installation instructions for the SB200-001 to mount the PECO Occupancy Sensor SB200-001.

LOCATE & MOUNT CO2 SENSOR

The T4900 can be configured for demand-controlled ventilation by using a PECO SC500 CO₂ Sensor (see Service Menu 170). For installation of the CO₂ Sensor, please see the PECO SC500 CO₂ Sensor Installation Instructions.

SENSOR WIRING FOR TEMPERATURE AVERAGING (OPTIONAL)

Figure 18.
Wiring four SP 155-017
(10K ohm) temperature sensors.





Figure 19.
Wiring nine SP 155-017
(10K ohm) temperature sensors.




SYSTEM SHUTDOWN FEATURE (OPTIONAL): WIRING DIAGRAMS

System shutdown provides the ability to shutdown all outputs via S1 Terminal (if enabled), and it may be used with or without application of a remote temperature probe. A dry contact switch can be connected to S1 input on the T4900 terminal block. When detected in an active state, all HVAC outputs are turned "OFF" (same as system off), and the Service Indicator (wrench) icon is displayed on the LCD. This feature is used for condensate overflow, door/window switch, or service mode detection. **Note:** All diagrams show the dry contact switch in the non-active state.

Use Service Menu 172 to configure the input. Select from Options 0-4 in Service Menu 172 ("0" is default). Options 0-4 in the following table correspond to the wiring diagram numbers (e.g., Option 1) below.

Menu	Feature	Options	Default	Description
172	System Shutdown (for S1 Terminal)	0-4	0	0 = Probe, no switch (Default) 1 = Shutdown on open 2 = Shutdown on closed 3 = Shutdown on open with remote temperature probe 4 = Shutdown on closed with remote temperature probe



**LOCATE & MOUNT PECO INDOOR REMOTE SENSOR
(SP 155-017)**

! WARNING

- READ THESE INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO INSTALL, OPERATE, OR SERVICE THIS SENSOR.
- Failure to observe safety information and comply with instructions could result in PERSONAL INJURY, DEATH AND/OR PROPERTY DAMAGE.
- To avoid electrical shock or damage to equipment, disconnect power before installing and use only wiring with insulation rated for full sensor operating voltage.
- This product, when installed, will be part of an engineered system whose specifications and performance characteristics are not designed or controlled by PECO. Review applications and national and local codes to assure that the installation will be functional and safe.
- Do not run low-voltage control wiring in the same conduit with high-voltage wiring.
- Use in indoor applications only.

Figure 20.
SP 155-017
Indoor
Remote Zone
Sensor,
front and side
view.





Figure 21.
SP155-017
Indoor Remote
Zone Sensor,
back view with
mounting holes.



INSTALLATION

1. **Mounting location.** Choose a location on an interior wall near the air return grille, about five feet (1.5 m) above floor level, where air circulation is good and temperature is average for the zone.

Avoid mounting the Indoor Remote Sensor in areas such as:

- Behind doors
- On outside walls, or any walls with unheated or uncooled areas behind the sensor
- In direct sunlight, or near any source of radiant heat that could affect the temperature measurements
- In line with the discharge air from the unit being controlled.

2. **Mount subbase.** Remove Sensor cover from the subbase, and mount subbase on the wall or in a 2" X 4" device box. Route the wires through the wire access hole in the subbase (see Fig. 22). Seal the hole in the wall behind the subbase.




Figure 22.
Mounting the
SP155-017
Indoor Remote
Zone Sensor.

WIRING

1. **Run wires.** Run wires between the unit control panel and the Sensor subbase.



CAUTION: Keep wires separate and routed away from any source of noise such as motors, fluorescent lights, and other wiring.

2. **Connect wires.** Connect the wiring to the terminals at the thermostat wallplate (S1 and SC) See Fig. 23, below.

Note: See Table 1 for terminal designations for the Indoor Remote Sensor.




Figure 23.
Wiring terminal
designations for
SP155-017
Indoor Remote
Zone Sensor.

3. **Replace cover.** Place Sensor cover back on the subbase, and snap it securely into place.
4. **Go to Service Menu 170.** Select option "01" to enable the Indoor Sensor (see Fig. 24).




Figure 24.
Service Menu
170 allows the
user to enable
the Indoor
Remote Zone
Sensor.

If the Indoor Remote Sensor is functioning properly, the primary display (center) shows the correct temperature taken at the location where Indoor Remote Sensor is currently installed (see Fig. 25).


Figure 25. Thermostat Display shows temperature from Zone Sensor if working properly.



TROUBLESHOOTING INDOOR REMOTE SENSOR

If the thermostat Home Display appears as follows (see Fig. 26), then the Indoor Remote Sensor is not connected properly. Two dashes and the Service Indicator (wrench) appear as the error message.

Figure 26. Thermostat Display shows Zone Sensor error message if Sensor is not working properly.



If the Indoor Remote Sensor is not connected properly, check the following:

- Make sure sensor is wired properly and connected to terminals S1 and SC on the thermostat wallplate (see Table 1, Terminal Designations & System Types).
- If using multiple sensors, make sure wiring follows diagrams in Sensor Wiring for Temperature Averaging.
- Make sure to select "01" in Service Menu 170.

LOCATE & MOUNT PECO OUTDOOR REMOTE SENSOR

Following are instructions on the PECO Outdoor Remote Sensor.

Mount the sensor where:

- It can measure true outdoor ambient temperature
- There is good air and circulation
- Surface is flat
- Wire distance between the sensors cannot be tampered with

Do not mount the sensor in any of the following:

- In direct sunlight
- Where hot or cold air blows on the sensor.
- Where discharge line from an outdoor compressor unit, vent, or fan causes inaccurate temperature readings
- Where snow, ice, or debris can cover it



MUST BE MOUNTED CABLE INLET FACING DOWN



CAUTION




DO NOT MOUNT WITH CABLE INLET FACING UP


OUTDOOR REMOTE SENSOR INSTALLATION

Use the following steps to mount the Outdoor Remote Sensor.


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5



STEP 6




WIRE PECO OUTDOOR REMOTE SENSOR

1. Wire the PECO Outdoor Remote Sensor to Terminal S1 and Sensor Common (SC) on the thermostat wallplate (see Fig. 27).
Note: See Table 1 for terminal designations for the Outdoor Remote Sensor.
2. Assure that Step 6 (previous section) is complete and the PECO Outdoor Remote Sensor is secure.
3. Plug the wiring passage using non-hardening caulk or putty.


Figure 27.

Wire PECO Remote Outdoor Sensor to Performance PRO wallplate, Terminal S1, SC.



4. Go to Service Menu 170, select from options 2-5, Outdoor Remote Sensor (see Fig.28).

Figure 28. Service Menu 170 allows the user to enable the Outdoor Remote Sensor.



ECONOMIZER / TIME-OF-DAY (TOD) LOGIC

Allow the outdoor or indoor temperature sensor to absorb the air for a minimum of five minutes before taking a reading. See Service Menu 370, which controls Economizer/ Outside air damper behavior. Table 6 shows the Economizer/TOD behaviors of available settings (Options include 0-4; 0 = OFF, which disables the Economizer function).

TABLE 6. Economizer Output

Effective Occupancy	Cooling Demand	370 = 1 (TOD)	370 = 2 (Economizer)
Occupied	N/A	ON Continuously	ON Continuously
Unoccupied	YES	OFF	ON (Cycles with demand)
	NO	OFF	OFF
Override	NA	ON Continuously	ON Continuously

Demand	System Mode	370 =3 (Continuous OA)	370 = 4 (Cycled OA)
Heating	Heat	ON Continuously	ON (Cycles with demand)
Cooling	Cool	ON Continuously	ON (Cycles with demand)
None	OFF	OFF	OFF
Heating or Cooling	Auto	ON Continuously	ON (Cycles with demand)

HEAT PUMP TEMPERATURE LOCKOUTS

Note: Heat Pump Compressor Lockouts (shown below) are only available if an Outdoor Temperature Sensor is applied and configured (See Table 1).

The options available in Service Menu 140 (below) are dependent on the selected System Type, Service Menu 110.

DUAL FUEL HEAT PUMP AND REMOTE OUTDOOR REMOTE SENSOR

In this operation, there is no external fossil fuel kit (dual fuel kit) installed; the thermostat controls this function:

1. Choose the correct heat pump application in Service Menu 110, System Type.
2. Choose Outdoor Temperature Sensor (Options 3 or 5) for Control Option in Service Menu 170, Remote Sensor.
3. Go to Service Menu 140, Auxiliary Heat, and choose "1."
4. Choose an appropriate temperature balance point in Service Menu 180, Heat Pump Compressor Lockout.

Operation in Heat Mode Above Balance Point (Outdoor Temperature)


When the outdoor temperature is above the selected balance point temperature (Service Menu 180), only the compressor operates and the fan (G Terminal) energizes when the thermostat calls for heat.

Operation in Heat Mode Below Balance Point (Outdoor Temperature)

When the outdoor temperature is below the selected balance point temperature (Service Menu 180), only the Fossil Fuel (auxiliary heat) operates and the fan (G Terminal) does not energize when the thermostat calls for heat.

FOSSIL FUEL AUXILIARY HEAT

If Service Menu 140 is set to "1" (fossil fuel Auxiliary Heat), the lockout control is as follows:



HEAT PUMP WITH AUXILIARY (BACKUP) HEAT AND OUTDOOR TEMPERATURE SENSOR

1. Choose the correct heat pump application in Service Menu 110, System Type.
2. In Service Menu 170, Remote Sensor, Choose Outdoor Temperature Sensor (Options 3/5) for Control Option.
3. Go to Service Menu 140, Auxiliary Heat, and choose "0."
4. Choose appropriate balance point in the Service Menu 180, Heat Pump Compressor Lockout.
5. Choose Auxiliary Lockout Temperature in Service Menu 190, Heat Pump Auxiliary Lockout.

Note: There is a minimum 5°F deadband between Compressor and Auxiliary Heat lockout temperatures.


Operation

When the outdoor temperature is:

- Below the Heat Pump Compressor Lockout Temperature, only the Auxiliary Heat operates.
- Above the Heat Pump Auxiliary Lockout Temperature, only the Compressor operates.
- Between the two temperatures, both the Compressor and Auxiliary Heat operate.

ELECTRIC AUXILIARY HEAT

If Service Menu 140 is set to "0" (electric Auxiliary Heat) the lockout control is as follows:



PART XII: T4900 SCHOOL SERIES CUSTOMIZED SETTINGS

School Schedule offers one-touch comfort conditioning, making it ideal for educational environments. Smart features like Adaptive Pre-Conditioning Schedule (APCS) simplify HVAC management because APCS adapts to variable occupancy patterns. APCS and School Schedule require input from Teacher/Override key or an Occupancy Sensor.

ENABLE SCHOOL SCHEDULE / TEACHER KEY

School Schedule has two scheduled events: Enabled and Disabled (see Table 7 below). The installer may choose the following School Schedule example. The installer may set default occupancy duration limits. The installer may select custom Heat/Cool Setpoints to be applied during the status periods: Occupied1, Unocc1; Occupied2, Unocc2. In routine operation, activation of School Schedule requires the user to press the **Teacher / Override** key or the connection and configuration of an occupancy sensor.

The following table shows an example of a School Schedule. School Schedule has two events, Enabled and Disabled, each with occupied and unoccupied settings.


TABLE 7. SCHOOL SCHEDULE EXAMPLE

SCHOOL SCHEDULE		
Enabled	Occupied1	Unocc1
Start Time: 6:00 AM	Heat Setpoint: 68°F (20°C) Cool Setpoint: 76°F (24°C) Occupied Duration: 4 HRS (See SM 396)	Heat Setpoint: 62°F (17°C) Cool Setpoint: 83°F (28°C)
Disabled	Occupied2	Unocc2
Start Time: 4:00 PM	Heat Setpoint: 64°F (18°C) Cool Setpoint: 81°F (27°C) Occupied Duration: 15 Min. (See SM 397)	Heat Setpoint: 58°F (14°C) Cool Setpoint: 85°F (29°C)

1. Press and hold down simultaneously **More** and **Teacher/Override** (lower left and lower right keys). **Note:** Service Menu 100 appears; "01" flashes below.
Note: At any time, user may select **Go Back** to abort or **Done** to save settings.

2. Press **▲ / ▼** to highlight option "04," selecting "School Schedule" format (see Fig. 29).

Figure 29. Selecting "04" in Service Menu 100 enables School Schedule.



3. Press **Done**. **Note:** If you wish to customize settings, see next section.

CUSTOMIZE SETTINGS FOR SCHOOL SCHEDULE (OPTIONAL)

Next, select settings for a Heat Setpoint and Cool Setpoint for Occupied1 and Unocc1 status periods to be applied in School Schedule Enabled.

1. Press **More** to view more options.
2. Press **Schedule** to select the days to which settings will be applied.
3. Press **▲ / ▼** to highlight day. **Note:** Selected day flashes (Note: Select **View** to modify an existing event).
4. Press **Edit** to apply scheduled events for the selected day(s).
5. Press **Select Day**. **Note:** To select day press **Select Day** on flashing day. (Continue pressing **Select Day** for multiple days; automatically advances to the next day.)
6. Press **▲ / ▼** to highlight the day(s) to be programmed. **Note:** Selected day(s) for scheduled events must be underlined.

7. Press **Next**. *Occupied1* and *Unocc1* appear flashing, with the start time shown.
Note: *Occupied1* and *Unocc1* represent School Schedule "Enabled" event.
8. At the flashing *Occupied1* and *Unocc1*, select **Next** (see Fig. 30).




Figure 30. In School Schedule Enabled, *Occupied1* flashes and Heat Setpoint appears.

9. At the flashing clock, press **▲ / ▼** to select a start time for School Schedule Enabled.
Note: Start time is adjustable by a quarter hour.
10. Press **Next**. **Note:** Heat Setpoint appears (flashing) in upper right (see Fig. 30).
11. Press **▲ / ▼** to select desired Heat Setpoint for School Schedule Enabled *Occupied1*.
12. Press **Next**. Cool Setpoint appears.
13. Press **▲ / ▼** to select a Cool Setpoint.
14. Press **Next**.
15. Now select a Heat Setpoint and Cool Setpoint for School Schedule Enabled *Unocc1*. Repeat steps 12-15 for the *Unocc1* settings of Schedule School Enabled.
16. Press **Next** after completing Heat/Cool Setpoints for School Schedule Enabled.
17. Select **Next** At the flashing block of *Occupied2* and *Unocc2*.
Note: *Occupied2* and *Unocc2* represent School Schedule "Disabled" event.
18. At the flashing clock, press **▲ / ▼** to select a start time for School Schedule Disabled *Occupied2*. **Note:** Start time adjustable by a quarter hour.
19. Press **Next**. Heat Setpoint appears (temperature flashing).
20. Press **▲ / ▼** to select Heat Setpoint to be applied at the start of the School Schedule Disabled *Occupied2* (see Fig. 31).




Figure 31. Select Heat Setpoint for *Occupied2* in School Schedule "Disabled."

21. Press **Next**. Cool Setpoint appears.
22. Press **▲ / ▼** to select Cool Setpoint for Schedule Disabled *Occupied2*.
23. Press **Next**. Heat Setpoint for *Unocc2* appears.
24. Now select a Heat Setpoint and Cool Setpoint for School Schedule Disabled *Unocc2*. Repeat steps 20-22 for the *Unocc2* settings of Schedule School Disabled.
25. Press **Done** to save all settings.

RESTRICTING DURATION OF SCHOOL SCHEDULE SETTINGS

The installer may adjust the default duration of the occupied and unoccupied status within Enabled and Disabled events, and adjust the maximum occupied time for which settings can be applied (see Table 2). If you wish to program these settings, continue as follows:

- To program the default occupied period in which School Schedule Enabled settings apply when the Teacher/Override key is pressed, see SM396, Default Occupied Duration When Enabled.
- To program the default occupied period in which School Schedule Disabled settings apply when the Teacher/Override key is pressed, see SM397, Default Occupied Duration When Disabled.
- To program the maximum occupied duration that the user can enter during Enabled event, see SM 398, Max. Occupied Duration When Enabled.
- To program the maximum occupied duration that the user can enter during Disabled event, see SM 399, Max. Occupied Duration When Disabled.
- To program the number of degrees that the Heat Setpoint and Cool Setpoint may be increased and decreased, upon pushing Teacher/Override, see SM 303-SM 305.


ENABLE ADAPTIVE PRECONDITIONING SCHEDULE

Adaptive Pre-Conditioning Schedule (APCS) is intended to pre-condition a room for occupancy based on weekly routines. An optional feature of School Schedule, APCS helps educational facilities meet clean air quality standards. The installer must select the number of weeks an occupancy event remains in memory (SM 392), the number of hours prior to occupancy to apply pre-purge (SM 390), and the heat/cool recovery rate (SM 460/470).

APCS is only initiated by occupancy. A user must press the Teacher key or an Occupancy Sensor must be applied. Thereafter, APCS applies pre-purge and heat/cool recovery settings before the weekly occupancy event. APCS continues to adjust to a user's weekly routine based upon whether occupancy is initiated within a consistent timeframe. APCS learns occupancy routines quickly and forgets them slowly.


1. Press, hold down simultaneously **More** and **Teacher /Override** (lower left and lower right) keys to enter Service Menus. Service Menu 100 appears.
2. Press **Next** to go to Service Menu 391.
3. Press **▲ / ▼** to select "01" to enable.
4. Press **Done** when finished.

Figure 32.
Enable
APCS in
Service
Menu 391.




5. Now assign the **number of weeks** that an APCS event will remain in the schedule. Advance to Service Menu 392. Default option is two (2) weeks. Note: APCS utilizes the **number of weeks** that the start time of an occupancy event remains in the schedule.
6. Select (0-4) the number of weeks that the start time of an occupancy event remains in the schedule (see Fig.33).

Figure 33.
Assign the
number
of weeks
that an
APCS event
remains in
schedule.



7. Optional: To clear the APCS schedule, advance to Service Menu 541 (see Fig. 34).
8. Press **▲ / ▼** and select "01," then press **Done**. Menu resets to "0" after the **Done** key is pressed.

Figure 34.
Clear the
memory for
APCS.



Note: In order for APCS to function properly, assure that:

- Occupancy Sensor is enabled—if used for application (see SM 388)
- School Schedule format is applied to thermostat (see SM 100)
- Pre-Occupancy Purge sets number of hours prior to occupied events (see SM 390)

ENABLE KEYPAD LOCKOUT

Keypad lockout blocks access to certain features of the thermostat but allows access to the Service Menus. After keypad lockout is enabled, the padlock icon will appear. Three levels of Keypad Lockout are available (see SM 340). **Note:** If option 3 is selected, all keys will be disabled except for the key combination used to enter into Service Menus (for restricting access to the Service Menus, see SM 341, PIN Access). In the following example, the installer will enable Keypad Lockout, Option 3, which disables all key functions, except for access to the Service Menus.

1. Press, hold down simultaneously **More** and **Teacher /Override** (lower left and lower right) keys to enter Service Menus. Service Menu 100 appears.
2. Press **Next** to go to Service Menu 340.
3. In Service Menu 340, select Option "03," which disables all keys (see Fig.35).




Figure 35.
Select
Option "03"
in Service
Menu 340
to disable all
keys.

4. Press **Done**. **Note:** After the above steps are complete, the Default Display is shown, in addition to a padlock icon at bottom (see Fig. 36).



Figure 36.
Default
Display after
Keypad
Lockout is
applied.

5. To reset Keypad Lockout to default setting (0, No Keypad Lockout), press and hold down simultaneously **More** and **Teacher /Override** (lower left and lower right) keys to enter Service Menus. Service Menu 100 appears.
6. Press **Next** to go to Service Menu 340 (see Fig. 37).




Figure 37.
In Service
Menu 340
Select
Option
"00" for No
Keypad
Lockout .

7. In Service Menu 340, select Option "00," which enables "No Keypad Lockout."

TABLE 3. TROUBLESHOOTING & FREQUENTLY ASKED QUESTIONS

In case of difficulty, try one of the following suggestions below.

Symptom	Potential Cause(s)	Solution
If display screen is blank	• Thermostat is not being powered	• Check to assure connection between Common (C) and (RC) for 24 VAC. • Check to assure that the metal jumper connects "RC" and "RH" (on single transformer system only). • Check to assure AA batteries are installed properly and are charged.
	• Default Display is set to "4" (None)	• Check Service Menu 520.
If display screen is blank AND system is running AC power only	• Power harvesting is enabled without battery support	• Install batteries and select "0" (disabled) in Service Menu 510 (to disable Power Harvesting).
If keys do not allow manual entry	• Keypad Lockout may be enabled	• Access Service Menu 340. Within this menu, select option "0" to assure there is no keypad lockout (so manual entry is enabled).
If Service Indicator (wrench) is on	• Remote temperature sensors may not be installed correctly or may be damaged.	• Check to assure that remote temperature sensor is connected properly. Ensure that the system uses PECO-approved sensor(s).
Setpoint limits do not change	• Heat or cool setpoint limit has been reached	• Check range limits and deadband (see Service Menus 290, 300, 380).
	• Keypad is locked	• See item above
If no heating or cooling is running, but there is a call for heat or cool (Heat/Cool appears on display) in Auto mode	• Heating or cooling equipment is not operating	• Check Service Menu 110 to assure that the correct option is selected to match the system type. • Check wiring, using output tests to verify (see Service Menus 600, 610, 620, 630, 640).
If heating and cooling system doesn't respond	• System type selection is incorrect	• Check Service Menu 110 to assure that the correct option is selected to match the system type.
If heating and cooling equipment are running at the same time	• System type selection is incorrect	• Check Service Menu 110 to assure that the correct option to match the system type is selected.
	• Heating and cooling wires are shorted together	• Separate the heating and cooling wires, using output tests to verify (see Service Menus 600, 610, 620, 630, 640).
Heat does not turn on (Heat is on continuously on display)	• Heating equipment failure • Loose or broken wire connection between heating equipment and thermostat	• Check for 24 VAC at the equipment on the secondary side of the transformer between the Power for Heating (RH) and the Common (C). • Check to assure 24 VAC connection between heat terminal (W1) and transformer Common (C). If 24 VAC is present, thermostat is functional. Check heating equipment to find cause of failure. If voltage is not present, check wire connection between the heating equipment and the thermostat.
If Demand Indicator light is red	• Heating is occurring	• No action is required.
If Demand Indicator light is green	• Cooling is occurring	• No action is required.
If Demand Indicator light is flashing	• An error has occurred • Remote sensor may be malfunctioning	• Check remote sensor wiring. • Verify that the sensor(s) are PECO supported products.
If heat pump issues cool air in heat mode or warm air in cool mode	• Changeover valve (B/O terminal) is not configured to match the heat pump	• Check Service Menu 130 to assure that the changeover valve (B/O terminal) is set to properly match the heat pump.
Cooling does not turn on (Cool is on display) in Auto mode	• Cooling equipment failure • Loose or broken wire between cooling equipment and thermostat	• Check for 24 VAC at the equipment on the secondary side of the transformer between the Power for Cooling (RC) and the Common (C). • Check to assure 24 VAC connection between the cool terminal (Y1) and transformer Common (C). If 24 VAC is present, thermostat is functional. Check cooling equipment to find cause of failure. If voltage is not present, check the wire connection between the cooling equipment and the thermostat.
If fan does not turn on when there is a demand for heat	• System type may be incorrect	• See Service Menu 110 and assure that the correct option is selected.
	• Fan control may be incorrect	• See Service Menu 120 and assure that the correct option is selected.
If heating system is running in the cool mode	• System type selection is incorrect	• Check Service Menu 110 to assure that the correct option is selected to match the system type.
If heating equipment does not turn off and heat temperature setting is set below room temperature	• Heating equipment is not a heat pump but system type selected is heat pump	• Check Service Menu 110 to assure that the correct option is selected to match the system type.
If the user cannot select the system setting for cool	• System type is set to Heat only or Heat only with fan	• Check Service Menu 110 to assure that the correct option is selected to match the system type.
If the user cannot select the system setting for heat	• System type is set to Cool only.	• Check Service Menu 110 to assure that the correct option is selected to match the system type.